



Analysis and Optimization of AlTiC CMP Using Advanced Heads

Brown, Feeney, Shumway
Axis Technology


18 Sept 2012

Outline

- Results with rigid plate carriers
- Tuning of modified Titan carrier tuning with single factors
- Initial oxide/AlTiC CMP data
- Simultaneous tuning of modified Titan
- Summary and Follow-up work

Rigid Plate Carrier Edge Exclusion

- Best NU only achieves 5mm edge exclusion at best
- Requires high downforce and slow speeds
 - Incompatible with most modern processes




200mm Mirra Taken Through Upgrades

- Started with Titan (3 zone) membrane carrier
 - Membrane enables front referencing technology
 - Flat edge to 3mm, some edge tuning
 - Has advantages for volume production applications
 - ISRM, multiplaten, etc.
- Upgrades have been available
 - Profiler (4 zone) head
 - Increased edge tuning
 - Contour (6 zone) head
 - Full radial control

Path for 150/200mm Legacy Tools


- Older equipment with rigid plate carriers being extended
 - IPEC 372M/472
 - Strasbaugh 6DS-SP/6EC
 - ViPRR controls retaining ring
 - Ebara EPO
 - Still good for lower volume / flexible purpose
- Carrier upgrade path developed
 - 200mm: ViPRR, Titan, Profiler, and Contour
 - 150mm: Titan and now Profiler (from AMAT)

AITiC Wafer Process on 6DS-SP/Titan



Uniformity improved with 8 psi 55 RPM process

Customer/New Processes on 472/Titan




Uniformity improved 5X, Rate 2x with new process

www.axustech.com




Edge Tuning on 472/Profiler



Dramatic changes in edge rate possible with Profiler
Similar results now available with modified Titan




Axis Technology Modified Titan 200mm Normalized Diameter Scan 3mm EE Oxide on Silicon Blanket Wafers



NU improved by raising the retaining ring pressure up to 7




Axis Technology Modified Titan 1 200mm Normalized Diameter Scan, 3mm EE Oxide on Silicon Blanket Wafers




Overall shape of edge can be driven by IT piston pressure

AlTiC Diameter scan, 60 sec at 5 psi, Initial BKM (Non-optimized*) 5mm Edge




Initial run using Axis Technology BKM prior to optimization
Even non-optimized process gives 2.0-2.6% radial NU at 5mm
Want to investigate tuning edge up and down

DOE with R Ring and Modified IT Plate




Ox on Si, Membrane 5 psi, Platen/Carrier 93/87 rpm
Retaining Ring 6.4-7.6 & IT bladder 4-6 (piston) psi
Rate at 3mm varies ~1500A/min

Rate Across Wafer Center



$p = 0.09$


$p < 0.01$



Model Rsq = 0.89


Parameters have influence on center rate
Likely the result of fluid film and temperature changes
Zone control will be evaluated as delta to center rate

Rate at 3mm from Edge



$p = 0.06$


$p < 0.01$



Model Rsq = 0.99


Retaining Ring pressure has large influence on 3mm rate

Rate at 6mm from Edge



$p < 0.01$


$p < 0.01$



Model Rsq = 0.97


Both factors influence 6mm rate
Can utilize higher pressure to raise 6mm rate without large effect on 3mm

Rate at 9mm from Edge



$p = 0.05$


$p < 0.01$




Model $Rsq = 0.94$

Both parameters have smaller effect on 9mm rate

Optimization of 6mm and 9mm Rates



Best uniformity
Want 0
Fix shape instead



Flattest edge
Want +100
Go beyond IT of 6

Summary and Follow-up

- Back referenced carriers create limits on non-uniformity and edge tuning as well as rate and cost of ownership
- Upgrading legacy tools with original Titan carriers enables gains in non-uniformity and rate/CoO
- Modifications to Titan IT done at Axus enable edge tuning that was previously only possible with Profiler
- Tuning characterized for easy optimization
- Latest results to be tested on AlTiC wafers