

Characterization of Dopant Activation, Mobility and Diffusion in Advanced Millisecond Laser Spike Annealing

Shaoyin Chen¹, Xiaoru Wang¹, Michael Thompson², Yun Wang¹,
Cam Lu¹, Jim McWhirter¹

¹ Ultratech Inc., 3050 Zanker Rd., San Jose, CA 95134 USA


² Cornell University, Ithaca, NY, USA

Feb 2, 2011



Outline

- **Advanced Dual-beam LSA system**
- **Effect of dwell time and multiple anneals**
 - Dopant diffusion
 - Sheet resistance
 - Junction leakage
- **Dopant activation & mobility study**
 - Sheet resistance
 - Mobility & active sheet concentration from Hall measurement
 - Model analysis
- **Conclusions**
- **Acknowledgement**

Annealing Technology and Time Scale



Advanced Dual-Beam LSA System




- A 2nd laser is introduced to the conventional SB-LSA system as a pre-heat laser

DB-LSA Advantages and Applications

DB-LSA offers great process flexibilities:

- ◆ T_{sub} , T_{int} & T_{pk}
- ◆ CO_2 dwell time
- ◆ Pre-heat laser dwell time
- ◆ CO_2 only process
- ◆ Pre-heat laser only process
- ◆ Dual-beam process



DB-LSA Applications


	Low T (Silicide Formation)	Stress Reduction (Junction Formation)	Long Dwell (Defect Annealing)
T_{sub}	< 250°C	~400°C	~400°C
T_{int}	Minimal	Low-Mid	High
Thermal budget	Negligible	Small	Large
T_{pk}	500-900°C	1100-1350°C	1100-1350°C

Outline

- Advanced Dual-beam LSA system
- **Effect of dwell time and multiple anneals**
 - Dopant diffusion
 - Sheet resistance
 - Junction leakage
- **Dopant activation & mobility study**
 - Sheet resistance
 - Mobility & active sheet concentration from Hall measurement
 - Model analysis
- **Conclusions**
- **Acknowledgement**


Design of Experiments for Dwell Time & Multi-Anneals Study

	Implant	Dwell (ms)	# of Anneals	LSA T (°C)	Metrology	
Short-mid dwell regime	Ge PAI+C+B 1E15 200eV	0.4~1.6	1~4	1150~1250	SIMS	RsL
	Ge PAI+C+B 1E15 500eV	0.4~1.6	1~4	1150~1250		
Long dwell regime	Ge PAI +B 2E15 500eV	10~20	1	1100~1225		




Effect of LSA Dwell Time

SIMS Profiles for Wafers w/
Different LSA Dwell Time




Rs & ΔX_j vs Dwell Time




- Rs decreases with dwell time
- X_j increases mildly with dwell time

Effect of Multiple LSA Anneals

SIMS Profiles for Wafers
w/ Multiple Anneals




R_s & ΔX_j vs Dwell Time




- Majority TED occurs at 1st anneal
- Subsequent anneals slightly deepens X_j

Multi-Anneals for 500eV B Implants


SIMS



Rs & ΔX_j vs No. of Anneals




Rs vs X_j for LSA w/i Short-Mid Dwell & Multiple Anneals




- Capability of fine-tuning of X_j with sub-nanometer precision
- Beneficial for junction engineering & device optimization

RsL Leakage Measurement

RsL Leakage vs LSA Temperature
[Wang et.al. IWJT 2010]




RsL Leakage vs No. of LSA Anneals



- Junction leakage can be reduced by
 - increasing LSA temperature or dwell time
 - additional LSA anneals


Dopant Diffusion w/i Long Dwell Time

SIMS Profiles for Wafers
w/i Short & Long Dwell



$\Delta X_j \sim 4\text{nm}$ for 0.8ms
 $\Delta X_j \sim 6\text{nm}$ for long dwell

Dwell Time Effect on Junction Leakage




- At the same annealing T, junction leakage can be improved w/i long dwell time

Outline


- Advanced Dual-beam LSA system
- Effect of dwell time and multiple anneals
 - Dopant diffusion
 - Sheet resistance
 - Junction leakage
- **Dopant activation & mobility study**
 - Sheet resistance
 - Mobility & active sheet concentration from Hall measurement
 - Model analysis
- Conclusions
- Acknowledgement

Design of Experiment for Dopant Activation & Mobility Study

Implant	Dwell (ms)	# of Anneals	LSA T (°C)	Metrology		
				Van der Pauw	Hall Measurement	SIMS
B 2E15 5keV	0.8~20	1	1150~1300	Rs	Ns, μ	carrier concentration



Van der Pauw Hall Measurement



Van der Pauw & Hall Measurement
sample patterning


$$N_s = \frac{I \cdot B}{q |V_H|} \times r_H$$

$$\mu = \frac{1}{q \cdot N_s \cdot R_s}$$

Hall scattering factor $r_H = 0.74$


A. T. Fiory et. Al. *Appl. Phys. Lett.*, vol. **74**(18), p. 2658, 1999.

Rs Measurement Results




- Rs decreases with LSA temperature

Hall Measurement Results



- μ has weak dependence w/ LSA temperature
- N_s increases dramatically w/ LSA temperature

Modeling of Dopant Activation



From SIMS profile, μ and n_s can be obtained:

$$\mu = \mu_0 e^{\frac{-p_c}{p}} + \frac{\mu_{max}}{1 + (p/C_r)^\alpha} - \frac{\mu_1}{1 + (C_s/p)^\beta}$$


(Masetti mobility model)

C_{max} can be obtained by solving

$$Rs = \frac{1}{q \int_0^{C_{max}} p \cdot \mu(z) dz} \quad \text{for } C_{max}$$

$$N_s = \int_0^{C_{max}} p dz$$


Experimental Results vs Model




- Overall good agreement between model & experimental results

Dwell Time Effect

Ns & Rs vs Annealing Dwell Time





C_{max} vs Annealing Dwell Time



- Rs decreases w/ dwell time
- At same annealing T, long dwell time improves activation

Thermal Activation Energy Extraction



D. Nobili et. al. "Solubility of B, Al, Ga, In, Tl, P, As and Sb in c-Si," *Property of Crystalline Silicon*, p. 620, 1999.

- Different dwell times (ms vs s) result in different E_a ?

Conclusions

- **DB-LSA offers great process flexibility and enables a wide ranges of LSA dwell time from sub-ms to tens of millisecond**
- **Rs, Xj & leakage have been examined for various dwell time & No. of anneals**
 - Rs, leakage ↓ w/i longer dwell time/multi-anneals
 - Xj slowly ↑ w/i longer dwell time/multi-anneals
 - LSA demonstrates sub-nm X_j tunability for precise junction engineering
- **Dopant activation has been evaluated with Hall Measurement**
 - Improved activation are observed w/i high LSA T or long dwell time
 - Model analysis shows good match w/i experimental results
 - Thermal activation energy of 1.6eV is extracted from experiments & model analysis

Short vs Long Dwell Process

Short dwell Process

- Better Rs-Xj performance
- Low stress relaxation
- High peak annealing T

- Insufficient lateral diffusion for MSA-only integration
- Defects and leakage existence at low T

Long dwell Process

- Low leakage
- Higher activation
- Controlled lateral diffusion

- Higher warpage
 - Limits peak T
 - Optical misalignment

DB-LSA provides extra flexibility in optimizing dopant activation, junction leakage, and wafer stress.

Acknowledgement

Authors would like to thank Varian Semiconductor Equipment Associate for providing part of the implants.

We also appreciate Byungki Jung and Ian Thompson for van der Pauw sample fabrication and mobility measurements.