Nanostructured Energy Conversion for Low-power Energy Harvesting Devices and Beyond for High-power 'Sun-to-fiber' Solar Devices

Michael Oye and Nobuhiko "Nobby" Kobayashi

Advanced Studies Laboratories and
Department of Electrical Engineering,
University of California Santa Cruz (UCSC)
NASA Ames Research Center,
Moffett Field (near Sunnyvale/Mountain View), CA

February 21, 2013

M. Oye's research acknowledgments

- UC Santa Cruz
 - Nobby Kobayashi, J. Varelas
- Research and Educational
 - Robert Cormia (Foothill College), W. Vercoutere (NASA), P. Minogue (UCSC), B. Le Boeuf (UCSC), T. Siegel (UCSC), G. Ringold (UCSC)
- NASA Ames Research Center
 - M. Meyyappan, J. Koehne, J. Li
- Others
 - M. Sanghadasa, T. Ngo-Duc, J. Gacusan, L. Dugacyzk

Outline

Part 1: Michael Oye

- Activities in Advanced Studies Laboratories (ASL), @ NASA
 Ames in Silicon Valley
- Educational activities in ASL (research, training, and characterization equipment)
- Equipment in UCSC MACS Facility
 at NASA Ames Research Center

 MATERIALS ANALYSIS FOR COLOR
 AT AMES RESEARCH CENTER
- Nanostructured energy conversion for Low-power Energy Harvesting Devices
 - Piezoelectric Nanowires

Part 2: Nobby Kobayashi

- Thermoelectric Nanowires
- 'Sun to Fiber" solar devices



Welcome to the Advanced Studies Laboratory

Advanced Studies Laboratory


Wenonah Vercoutere, ASL Co-Director for NASA Ames
Burney Le Boeuf, ASL Co-Director for UCSC
Michael Oye, Associate ASL Director for UCSC and
Director of the Materials Analysis for
Collaborative Science (MACS) Facility
Joseph Varelas, Lab Manager, MACS Facility
Peter Minogue, Marketing and Outreach, ASL

NASA Ames Research Center

Steven Zornetzer, Associate Center Director

University of California Santa Cruz Silicon Valley Initiatives

Gordon Ringold, *Director* Tedd Siegel, *Assistant Vice Provost, Associate Director*




March 2012





Advanced Studies Laboratory (ASL) Research Areas



MACS Facility:

Materials Analysis and Characterization for new MATERIALS across traditional disciplines and establishments

MATERIALS ANALYSIS FOR COLLABORATIVE SCIENCE
AT AMES RESEARCH CENTER IN SILICON VALLEY



Advanced Studies Laboratory Mission Statement

Purpose of ASL: Partnership between UCSC and NASA Ames to provide cohesive management and oversight for fostering collaborative research in Silicon Valley

The **mission** of ASL is to create an open and dynamic environment supporting research, technology development, and <u>educational</u> opportunities to benefit both parties.

We are cross-disciplinary and cross-institutional.

→ Adapting to Changing Classroom Environment

Michael Oye (UCSC and SJSU) & Robert Cormia (Foothill College), with Wenonah Vercoutere (NASA), Nobby, Kobayashi (UCSC), Joey Varelas (UCSC), Peter Minogue (UCSC), and Burney Le Boeuf (UCSC)

"Adapting to a Changing Classroom Environment"... *from what*?

- Interdisciplinary Research Activities
 - -Subject and Equipment

- Online Course Delivery
 - -Why do we even need classrooms?

What we are doing in the Advanced Studies Laboratories in Silicon Valley to address the changing classroom environment:

- Integrating innovative methods for Silicon Valley
 - Teach what to do with information
 - Be flexible (Subject & scheduling → No "Typical" Student)
 - Interactive engagement with hands-on lab projects
 - Scalable (Infrastructure & model)
 - Place for new ideas to grow → I²
 Incubating *Innovation*, Incubating *Individuals*, Incubating *Ideas*, etc...

(I², term coined by Bob Cormia, Foothill College)

Timeline

Spring '13

UCSC EE293
 Solid State
 class with lab
 component in
 UCSC MACS,
 supported by
 Foothill
 College

Fall '13

- UCSC EE293,
 Semiconductor
 Processing and
 Characterization
- SJSU MatE 265,
 Fundamentals of Nanomaterials
- Foothill College,
 Nanocharacterization
- UCSC Extension

Future

 Integration of Laboratory components to MS EE Courses for Silicon Valley Professionals

http://www.ee.ucsc.edu/g raduates/silicon-valley

Summer '13 • **L**

 Course development for integration of coordinated courses between UCSC, SJSU, and Foothill College

2014

 Expand laboratory activities in courses with UCSC Extension, Foothill College, and in MACS/ASL





http://macs.advancedstudieslabs.org/

moye@ucsc.edu

UCSC MACS Facility has Materials Characterization instruments available, on a cost recovery, with onsite Technical Staff

- SEM w/ EDS (1-2 nm resolution)
- TEM w/EDS (~0.1 nm resolution)
- Metal and Dielectric sputtering, and others
- Educational Case Study:
 - Students needed equipment for project
 - Industry needed student interns and academic experience, provided cost recovery of equipment for project use.







http://macs.advancedstudieslabs.org/

moye@ucsc.edu

Hitachi S-4800 II FE SEM

- Field Emission Scanning Electron Microscope with light element analysis and EDS.
- 1-2 nanometer range resolution.
- Dual Secondary Electron (SE) detector system for high resolution imaging.
- Backscatter electron (BSe) detector for analysis of insulating samples.









http://macs.advancedstudieslabs.org/

moye@ucsc.edu

Hitachi H-9500 300kV TEM

- Ultra high-resolution microscope with resolution of 0.10 nm.
- High mag, high sensitivity bottom mount camera for materials science and diffraction studies.
- High performance energy dispersive X-ray spectroscopy (EDS).
- Magnification: 200 –1500kX.



Materials characterized in UCSC MACS Facility at NASA Ames

Nanowires

- Metal oxides & compound semiconductors
 - SEM
 - TEM
 - Ion Beam Sputtering for metals deposition

For Low-Power Energy Harvesting

- Take "wasted" energy that would have otherwise been lost
 - Vibrations → Mechanical to Electrical (Piezoelectric)
 - Thermal → Heat to Electrical (Thermoelectric)


How much power?

Piezoelectric: ~330 μW/cm³

Thermoelectric: $^40 \,\mu\text{W/cm}^3$

World generation capacity	4 terawatts	10 ¹²
Power station	1 gigawatt	10 ⁹
House	10 kilowatts	10 ⁴
Person, lightbulb	100 watts	10 ²
Laptop, heart	10 watts	10 ¹
Cellphone	1 watt	10 ⁰
Wireless sensor	1 milliwatt	10 -3
Wristwatch	1 microwatt	10 -6
Cellphone signal	1 nanowatt	10 -9

Piezoelectric Effect



http://bostonpiezooptics.com/images/content/Fig1-DirectPiezoEffect.jpg


$$V_{out} = h\Delta t$$

h is piezoelectric constant Δt is change in thickness

$$\frac{Force}{Area} = E\varepsilon$$


E is Elastic Modulus ϵ is strain (or Δt)

Tradeoff is P=iV; Charge is dependent on volume



G. Wang and X. Li, Appl. Phys. Lett. **91**, 231912 (2007).


Some Examples of Low-Power Piezoelectric Energy Harvesting



http://ecofriend.com/wp-content/uploads/2012/07/piezo-tree_1_pmPls_69.jpg



http://cdn.physorg.com/newman/ gfx/news/2007/EnergyHarvestingB ackpack.png




http://itp.nyu.edu/~rcc273/spring 2007/itpenergy/images/shoeImag es/shoePlunger.jpg

Piezoelectric Nanowire Device Integration

Nanowire Growth

Some examples:

- -Template-directed
- -Free standing (or horizontal growth)
- Vapor Liquid Solid (VLS)
- Vapor Solid (VS)



Device integration

- Making electrodes
- Extracting electrical current

Image from K.A. Dick, Progress in Crystal Growth and Characterization of Materials Volume 54, Issues 3–4, (2008)


Controlled Growth of Vertical ZnO Nanowires on Copper Substrate

T.-T. Ngo-Duc, J. Gacusan, N.P. Kobayashi,
 M. Sanghadasa, M. Meyyappan, M.M. Oye
 Applied Physics Letters 102, 083105 (2013)

Growth of Nanowires with varying diameters


- -Engineer Piezoelectric response
- -Engineer top electrode contact

Oxygen concentration has an impact



Ngo-Duc et al, APL 2013

Multiple segments



Zn flux constant
More relative oxygen -> Gets narrower
O arrives before Zn adatoms can migrate

Ngo-Duc et al, APL 2013